



DRW. DR150007

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PVM 1 | PUMP MODEL | | | | | | | | | | | | | | | | | |
|-----------------------|-------------|------------------------------|--------------------|---|--------------------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|------|----------|------|----------|------|----------|------|
| RECOMMENDED PARTS KIT | N° RIF. KIT | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 1-2 F M | PVM 1-2 F T | PVM 1-3 F M | PVM 1-3 F T | PVM 1-4 F M | PVM 1-4 F T | PVM 1-5 F M | PVM 1-5 F T | PVM 1-6 F M | PVM 1-6 F T | PVM 1-7 F M | | | | | | | |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 | NUT (TIE ROD LOCKING -) | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | | | | | |
| | | | 214 | WASHER | ZBR50680 | 4 pc | ZBR50690 | 4 pc | ZBR50700 | 4 pc | ZBR50710 | 4 pc | ZBR50720 | 4 pc | ZBR50730 | 4 pc | | | | | | |
| | | | 339 | ROD | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | | | | | |
| | 200 | BOLTS AND SCREWS KIT | 435 | SPACER | ZBR50140 | | | | | | | | | | | 1 pc | | | | | | |
| | | | 73 | NUT | | | | | | | | | | | | 1 pc | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | | 1 pc | | | | | | |
| | | | 477 | SPACER | | | | | | | | | | | | 1 pc | | | | | | |
| | 201 | GASKET KIT | 516 | O-RING | ZBR50070 (EPDM standard) | | | | | | | | | | | 1 pc | | | | | | |
| | | | 412 | GASKET | ZBR50080 (Viton) | | | | | | | | | | | 3 pc | | | | | | |
| | | | 25 | O-RING (PUMP BODY -) | | | | | | | | | | | | 2 pc | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) | ZBR50020 | | | | | | | | | | | 1 pc | | | | | | |
| | | | 487 | BEARING | | | | | | | | | | | | 1 pc | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | | 1 pc | | | | | | |
| | | | 479 | SPACER | | | | | | | | | | | | 1 pc | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | ZBR50050 | | | | | | | | | | | 1 pc | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 | CHAMBER (UPPER - WITH DIFFUSER) | ZBR50030 | | | | | | | | | | | 1 pc | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | | 1 pc | | | | | | |
| | | | 478 | SPACER | | | | | | | | | | | | 1 pc | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | ZBR50000 | | | | | | | | | | | 1 pc | | | | | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | ZBR50170 | | | | | | | | | | | 1 pc | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR21130 | 1 pc | ZBR21140 | 1 pc | ZBR21130 | 1 pc | ZBR21140 | 1 pc | ZBR21130 | 1 pc | ZBR21140 | 1 pc | ZBR21130 | 1 pc | ZBR21140 | 1 pc | ZBR21130 | 1 pc |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | ZBR50210 | | | | | | | | | | | 4 pc | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR50460 | 1 pc | ZBR50470 | 1 pc | ZBR50480 | 1 pc | ZBR50490 | 1 pc | ZBR50500 | 1 pc | ZBR50510 | 1 pc | | | | | | |
| | | | 273 | RING (STOP -) | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR50090 | | | | | | | | | | | 1 pc | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | ZBR50180 | | | | | | | | | | | 1 pc | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | ZBR50120 | | | | | | | | | | | 4 pc | | | | | | |
| | | | 414 | GUARD COUPLING | | | | | | | | | | | | 2 pc | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 286 | CHAMBER (INTERMEDIATE - W/O DIFFUSER) | ZBR50010 | | | | | | | | | | | 1 pc | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | | 1 pc | | | | | | |
| | | | 435 | SPACER | | | | | | | | | | | | 1 pc | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR50240 | 1 pc | ZBR50250 | 1 pc | ZBR50260 | 1 pc | ZBR50270 | 1 pc | ZBR50280 | 1 pc | ZBR50290 | 1 pc | | | | | | |
| * | 475 | WEAR RINGS KIT | 276 | RING (GUIDE -) | ZBR50060 | | | | | | | | | | | 1 pc | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | | 1 pc | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | ZBR50040 | | | | | | | | | | | 1 pc | | | | | | |
| | | | 36 | RING (ELASTIC -) | | | | | | | | | | | | 1 pc | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 | NOZZLE (AIR -) | ZBR50150 | | | | | | | | | | | 1 pc | | | | | | |
| | | | 5 | PLUG (FILL -) | | | | | | | | | | | | 1 pc | | | | | | |
| | | | 412 | GASKET | | | | | | | | | | | | 2 pc | | | | | | |



DRW. DR150007

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | PVM 1 | | PUMP MODEL | | | | | | | | | | | | | | | | | | | | | |
|-----------------------|-------------|------------------------------|--------------------|---|-------------|-------------|-------------|-------------|-------------|--------------------------|--------------|--------------|--------------|--------------|--------------|----------|----------|------|----------|------|----------|------|----------|------|----------|------|
| RECOMMENDED PARTS KIT | N° RIF. KIT | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 1-7 F T | PVM 1-8 F M | PVM 1-8 F T | PVM 1-9 F M | PVM 1-9 F T | PVM 1-10 F M | PVM 1-10 F T | PVM 1-11 F M | PVM 1-11 F T | PVM 1-12 F M | PVM 1-12 F T | | | | | | | | | | | |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 | NUT (TIE ROD LOCKING -) | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | | | | | | | | | | |
| | | | 214 | WASHER | 4 pc | ZBR50730 | 4 pc | ZBR50740 | 4 pc | ZBR50750 | 4 pc | ZBR50760 | 4 pc | ZBR50770 | 4 pc | ZBR50780 | | | | | | | | | | |
| | | | 339 | ROD | 4 pc | | | | 4 pc | | | | 4 pc | | 4 pc | | | | | | | | | | | |
| | 200 | BOLTS AND SCREWS KIT | 435 | SPACER | | | | | | ZBR50140 | | | | | 1 pc | | | | | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | | 1 pc | | | | | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | 1 pc | | | | | | | | | | | |
| | | | 477 | SPACER | | | | | | | | | | | 1 pc | | | | | | | | | | | |
| | 201 | GASKET KIT | 516 | O-RING | | | | | | ZBR50070 (EPDM standard) | | | | | 1 pc | | | | | | | | | | | |
| | | | 412 | GASKET | | | | | | ZBR50080 (Viton) | | | | | 3 pc | | | | | | | | | | | |
| | | | 25 | O-RING (PUMP BODY -) | | | | | | | | | | | 2 pc | | | | | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) | | | | | | ZBR50020 | | | | | 1 pc | | | | | | | | | | | |
| | | | 487 | BEARING | | | | | | | | | | | 1 pc | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | 1 pc | | | | | | | | | | | |
| | | | 479 | SPACER | | | | | | | | | | | 1 pc | | | | | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | | | | | | ZBR50050 | | | | | 1 pc | | | | | | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 | CHAMBER (UPPER - WITH DIFFUSER) | | | | | | ZBR50030 | | | | | 1 pc | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | 1 pc | | | | | | | | | | | |
| | | | 478 | SPACER | | | | | | | | | | | 1 pc | | | | | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | | | | | | ZBR50000 | | | | | 1 pc | | | | | | | | | | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | | | | | | ZBR50170 | | | | | 1 pc | | | | | | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR21140 | 1 pc | ZBR21150 | 1 pc | ZBR21160 | 1 pc | ZBR21150 | 1 pc | ZBR21160 | 1 pc | ZBR21150 | 1 pc | ZBR21160 | 1 pc | ZBR21150 | 1 pc | ZBR21160 | 1 pc | ZBR21210 | 1 pc | ZBR50900 | 1 pc |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | | | | | | ZBR50210 | | | | | 4 pc | ZBR50220 | 4 pc | | | | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | 1 pc | ZBR50510 | 1 pc | ZBR50520 | 1 pc | ZBR50530 | 1 pc | ZBR50540 | 1 pc | ZBR50550 | 1 pc | ZBR50560 | 1 pc | | | | | | | | | |
| | | | 273 | RING (STOP -) | 1 pc | | | | | | | | | | 1 pc | | 1 pc | | | | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | | | | | | ZBR50090 | | | | | 1 pc | ZBR50100 | 1 pc | | | | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | | | | | | ZBR50180 | | | | | 1 pc | ZBR50190 | 1 pc | | | | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | | | | | | ZBR50120 | | | | | 4 pc | | 2 pc | | | | | | | | | |
| | | | 414 | GUARD COUPLING | | | | | | | | | | | 1 pc | | 1 pc | | | | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 286 | CHAMBER (INTERMEDIATE - W/O DIFFUSER) | | | | | | ZBR50010 | | | | | 1 pc | | 1 pc | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | 1 pc | | 1 pc | | | | | | | | | |
| | | | 435 | SPACER | | | | | | | | | | | 1 pc | | 1 pc | | | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR50290 | 1 pc | ZBR50300 | 1 pc | ZBR50310 | 1 pc | ZBR50320 | 1 pc | ZBR50330 | 1 pc | ZBR50340 | 1 pc | | | | | | | | | | |
| * | 475 | WEAR RINGS KIT | 276 | RING (GUIDE -) | | | | | | ZBR50060 | | | | | 1 pc | | 1 pc | | | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | 1 pc | | 1 pc | | | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | | | | | | ZBR50040 | | | | | 1 pc | | 1 pc | | | | | | | | | |
| | | | 36 | RING (ELASTIC -) | | | | | | | | | | | 1 pc | | 1 pc | | | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT B) | 78 | NOZZLE (AIR -) | | | | | | ZBR50150 | | | | | 1 pc | | 1 pc | | | | | | | | | |
| | | | 5 | PLUG (FILL -) | | | | | | | | | | | 1 pc | | 1 pc | | | | | | | | | |
| | | | 412 | GASKET | | | | | | | | | | | 2 pc | | 2 pc | | | | | | | | | |



DRW. DR150007

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | PVM 1 | | PUMP MODEL | | | | | | | | | | | | | | | | | | |
|-----------------------|-------------|------------------------------|--------------------|---|--------------------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|------|----------|------|----------|------|----------|------|
| RECOMMENDED PARTS KIT | N° RIF. KIT | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 1-13 F M | PVM 1-13 F T | PVM 1-15 F M | PVM 1-15 F T | PVM 1-17 F M | PVM 1-17 F T | PVM 1-19 F M | PVM 1-19 F T | PVM 1-21 F M | PVM 1-21 F T | PVM 1-23 F M | | | | | | | |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 | NUT (TIE ROD LOCKING -) | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | | | | | |
| | | | 214 | WASHER | ZBR50790 | 4 pc | ZBR50800 | 4 pc | ZBR50810 | 4 pc | ZBR50820 | 4 pc | ZBR50830 | 4 pc | ZBR50840 | 4 pc | | | | | | |
| | | | 339 | ROD | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | | | | | |
| | 200 | BOLTS AND SCREWS KIT | 435 | SPACER | ZBR50140 | | | | | | | | | | 1 pc | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | | 1 pc | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | 1 pc | | | | | | | |
| | | | 477 | SPACER | | | | | | | | | | | 1 pc | | | | | | | |
| | 201 | GASKET KIT | 516 | O-RING | ZBR50070 (EPDM standard) | | | | | | | | | | 1 pc | | | | | | | |
| | | | 412 | GASKET | ZBR50080 (Viton) | | | | | | | | | | 3 pc | | | | | | | |
| | | | 25 | O-RING (PUMP BODY -) | | | | | | | | | | | 2 pc | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) | ZBR50020 | | | | | | | | | | 1 pc | | | | | | | |
| | | | 487 | BEARING | | | | | | | | | | | 1 pc | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | 1 pc | | | | | | | |
| | | | 479 | SPACER | | | | | | | | | | | 1 pc | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | ZBR50050 | | | | | | | | | | 1 pc | | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 | CHAMBER (UPPER - WITH DIFFUSER) | ZBR50030 | | | | | | | | | | 1 pc | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | 1 pc | | | | | | | |
| | | | 478 | SPACER | | | | | | | | | | | 1 pc | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | ZBR50000 | | | | | | | | | | 1 pc | | | | | | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | ZBR50170 | | | | | | | | | | 1 pc | | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR21210 | 1 pc | ZBR50900 | 1 pc | ZBR21210 | 1 pc | ZBR50900 | 1 pc | ZBR50910 | 1 pc | ZBR50920 | 1 pc | ZBR50910 | 1 pc | ZBR50920 | 1 pc | ZBR50910 | 1 pc |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | ZBR50220 | | | | | | | | | | 4 pc | | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR50570 | 1 pc | ZBR50580 | 1 pc | ZBR50590 | 1 pc | ZBR50600 | 1 pc | ZBR50610 | 1 pc | ZBR50620 | 1 pc | | | | | | |
| | | | 273 | RING (STOP -) | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR50100 | | | | | | | | | | 1 pc | | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | ZBR50190 | | | | | | | | | | 1 pc | | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | ZBR50120 | | | | | | | | | | 4 pc | | | | | | | |
| | | | 414 | GUARD COUPLING | | | | | | | | | | | 2 pc | | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 286 | CHAMBER (INTERMEDIATE - W/O DIFFUSER) | ZBR50010 | | | | | | | | | | 1 pc | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | 1 pc | | | | | | | |
| | | | 435 | SPACER | | | | | | | | | | | 1 pc | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR50350 | 1 pc | ZBR50360 | 1 pc | ZBR50370 | 1 pc | ZBR50380 | 1 pc | ZBR50390 | 1 pc | ZBR50400 | 1 pc | | | | | | |
| * | 475 | WEAR RINGS KIT | 276 | RING (GUIDE -) | ZBR50060 | | | | | | | | | | 1 pc | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | 1 pc | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | ZBR50040 | | | | | | | | | | 1 pc | | | | | | | |
| | | | 36 | RING (ELASTIC -) | | | | | | | | | | | 1 pc | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT B) | 78 | NOZZLE (AIR -) | ZBR50150 | | | | | | | | | | 1 pc | | | | | | | |
| | | | 5 | PLUG (FILL -) | | | | | | | | | | | 1 pc | | | | | | | |
| | | | 412 | GASKET | | | | | | | | | | | 2 pc | | | | | | | |



DRW. DR150007

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | PVM 1 | | PUMP MODEL | | | | | | | | | | |
|-----------------------|-------------|------------------------------|--------------------|---|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| RECOMMENDED PARTS KIT | N° RIF. KIT | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 1-23 F T | PVM 1-25 F M | PVM 1-25 F T | PVM 1-27 F M | PVM 1-27 F T | PVM 1-30 F M | PVM 1-30 F T | PVM 1-33 F M | PVM 1-33 F T | PVM 1-36 F M | PVM 1-36 F T |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 | NUT (TIE ROD LOCKING -) | | | | | | | | | | | |
| | | | 214 | WASHER | ZBR50840 | ZBR50850 | | ZBR50860 | | ZBR50870 | | ZBR50880 | | ZBR50890 | |
| | | | 339 | ROD | | | | | | | | | | | |
| | 200 | BOLTS AND SCREWS KIT | 435 | SPACER | | | | | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | |
| | | | 477 | SPACER | | | | | | | | | | | |
| | 201 | GASKET KIT | 516 | O-RING | | | | | | | | | | | |
| | | | 412 | GASKET | | | | | | | | | | | |
| | | | 25 | O-RING (PUMP BODY -) | | | | | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) | | | | | | | | | | | |
| | | | 487 | BEARING | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | |
| | | | 479 | SPACER | | | | | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | | | | | | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 | CHAMBER (UPPER - WITH DIFFUSER) | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | |
| | | | 478 | SPACER | | | | | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | | | | | | | | | | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | | | | | | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR50920 | ZBR30720 | ZBR50930 | ZBR30720 | ZBR50930 | ZBR30720 | ZBR50930 | ZBR50940 | ZBR50950 | ZBR50940 | ZBR50950 |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | ZBR50220 | | | | | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR50620 | ZBR50630 | | ZBR50640 | | ZBR50650 | | ZBR50660 | | ZBR50670 | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR50100 | | | | | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | ZBR50190 | | | | | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | ZBR50120 | | | | | | | | | | |
| | | | 414 | GUARD COUPLING | | | | | | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 286 | CHAMBER (INTERMEDIATE - W/O DIFFUSER) | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | |
| | | | 435 | SPACER | | | | | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR50400 | ZBR50410 | | ZBR53680 | | ZBR53690 | | ZBR53700 | | ZBR53710 | |
| * | 475 | WEAR RINGS KIT | 276 | RING (GUIDE -) | | | | | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | | | | | | | | | | | |
| | | | 36 | RING (ELASTIC -) | | | | | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT B) | 78 | NOZZLE (AIR -) | | | | | | | | | | | |
| | | | 5 | PLUG (FILL -) | | | | | | | | | | | |
| | | | 412 | GASKET | | | | | | | | | | | |



DRW. DR150007

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PVM 3 | PUMP MODEL | | | | | | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--------------------|---|--------------------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|----------|------|----------|------|----------|------|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 3-2 F M | PVM 3-2 F T | PVM 3-3 F M | PVM 3-3 F T | PVM 3-4 F M | PVM 3-4 F T | PVM 3-5 F M | PVM 3-5 F T | PVM 3-6 F M | PVM 3-6 F T | | | | | | |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 | NUT (TIE ROD LOCKING -) | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | | | | | |
| | | | 214 | WASHER | ZBR50680 | 4 pc | ZBR50690 | 4 pc | ZBR50700 | 4 pc | ZBR50710 | 4 pc | ZBR50720 | 4 pc | | | | | | |
| | | | 339 | ROD | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | | | | | |
| | 200 | BOLTS AND SCREWS KIT | 435 | SPACER | ZBR50140 | | | | | | | | | 1 pc | | | | | | |
| | | | 73 | NUT | | | | | | | | | | 1 pc | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | 1 pc | | | | | | |
| | | | 477 | SPACER | | | | | | | | | | 1 pc | | | | | | |
| | 201 | GASKET KIT | 516 | O-RING | ZBR50070 (EPDM standard) | | | | | | | | | 1 pc | | | | | | |
| | | | 412 | GASKET | ZBR50080 (Viton) | | | | | | | | | 3 pc | | | | | | |
| | | | 25 | O-RING (PUMP BODY -) | | | | | | | | | | 2 pc | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) | ZBR51040 | | | | | | | | | 1 pc | | | | | | |
| | | | 487 | BEARING | | | | | | | | | | 1 pc | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | 1 pc | | | | | | |
| | | | 479 | SPACER | | | | | | | | | | 1 pc | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | ZBR50050 | | | | | | | | | 1 pc | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 | CHAMBER (UPPER - WITH DIFFUSER) | ZBR51050 | | | | | | | | | 1 pc | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | 1 pc | | | | | | |
| | | | 478 | SPACER | | | | | | | | | | 1 pc | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | ZBR51020 | | | | | | | | | 1 pc | | | | | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | ZBR50170 | | | | | | | | | 1 pc | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR21130 | 1 pc | ZBR21140 | 1 pc | ZBR21130 | 1 pc | ZBR21140 | 1 pc | ZBR21130 | 1 pc | ZBR21140 | 1 pc | ZBR21150 | 1 pc | ZBR21160 | 1 pc |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | ZBR50210 | | | | | | | | | 4 pc | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR50460 | 1 pc | ZBR50470 | 1 pc | ZBR50480 | 1 pc | ZBR50490 | 1 pc | ZBR50500 | 1 pc | | | | | | |
| | | | 273 | RING (STOP -) | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR50090 | | | | | | | | | 1 pc | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | ZBR50180 | | | | | | | | | 1 pc | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | ZBR50120 | | | | | | | | | 4 pc | | | | | | |
| | | | 414 | GUARD COUPLING | | | | | | | | | | 2 pc | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 286 | CHAMBER (INTERMEDIATE - W/O DIFFUSER) | ZBR51030 | | | | | | | | | 1 pc | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | 1 pc | | | | | | |
| | | | 435 | SPACER | | | | | | | | | | 1 pc | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR50240 | 1 pc | ZBR50250 | 1 pc | ZBR50260 | 1 pc | ZBR50270 | 1 pc | ZBR50280 | 1 pc | | | | | | |
| * | 475 | WEAR RINGS KIT | 276 | RING (GUIDE -) | ZBR50060 | | | | | | | | | 1 pc | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | 1 pc | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | ZBR50040 | | | | | | | | | 1 pc | | | | | | |
| | | | 36 | RING (ELASTIC -) | | | | | | | | | | 1 pc | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 | NOZZLE (AIR -) | ZBR50150 | | | | | | | | | 1 pc | | | | | | |
| | | | 5 | PLUG (FILL -) | | | | | | | | | | 1 pc | | | | | | |
| | | | 412 | GASKET | | | | | | | | | | 2 pc | | | | | | |



DRW. DR150007

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PVM 3 | PUMP MODEL | | | | | | | |
|-----------------------|--------------|------------------------------|--------------------|---|--------------------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 3-21 F T | PVM 3-23 F T | PVM 3-25 F T | PVM 3-27 F T | PVM 3-29 F T | PVM 3-31 F T | PVM 3-33 F T | PVM 3-36 F T |
| | 82 | TIE ROD KIT (PUMP BODY ~) | 97 | NUT (TIE ROD LOCKING ~) | | | | | | | | |
| | | | 214 | WASHER | ZBR50830 | ZBR50840 | ZBR50850 | ZBR50860 | ZBR51160 | ZBR51170 | ZBR50880 | ZBR50890 |
| | | | 339 | ROD | | | | | | | | |
| | 200 | BOLTS AND SCREWS KIT | 435 | SPACER | ZBR50140 | | | | | | | |
| | | | 73 | NUT | | | | | | | | |
| | | | 273 | RING (STOP ~) | | | | | | | | |
| | | | 477 | SPACER | | | | | | | | |
| | 201 | GASKET KIT | 516 | O-RING | ZBR50070 (EPDM standard) | | | | | | | |
| | | | 412 | GASKET | ZBR50080 (Viton) | | | | | | | |
| | | | 25 | O-RING (PUMP BODY ~) | | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. ~) | ZBR51040 | | | | | | | |
| | | | 487 | BEARING | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | |
| | | | 479 | SPACER | | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL ~) | ZBR50050 | | | | | | | |
| | 323 | STAGE (INTERMEDIATE ~)KIT | 308 | CHAMBER (UPPER ~ WITH DIFFUSER) | ZBR51050 | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | |
| | | | 478 | SPACER | | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | ZBR51020 | | | | | | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP ~) | ZBR50170 | | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR50950 | | | | ZBR50960 | | | |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | ZBR50230 | | | | ZBR51080 | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR50610 | ZBR50620 | ZBR50630 | ZBR51110 | ZBR51120 | ZBR51130 | ZBR51140 | ZBR51150 |
| | | | 273 | RING (STOP ~) | | | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP ~) | ZBR50110 | | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | ZBR50200 | | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | ZBR50130 | | | | | | | |
| | | | 414 | GUARD COUPLING | | | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 286 | CHAMBER (INTERMEDIATE ~ W/O DIFFUSER) | ZBR51030 | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | |
| | | | 435 | SPACER | | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR50390 | ZBR50400 | ZBR50410 | ZBR53680 | ZBR51090 | ZBR51100 | ZBR53700 | ZBR53710 |
| * | 475 | WEAR RINGS KIT | 276 | RING (GUIDE ~) | ZBR50060 | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING ~) | | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE ~) | ZBR50040 | | | | | | | |
| | | | 36 | RING (ELASTIC ~) | | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 | NOZZLE (AIR ~) | ZBR50150 | | | | | | | |
| | | | 5 | PLUG (FILL ~) | | | | | | | | |
| | | | 412 | GASKET | | | | | | | | |



DRW. DR150007

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PVM 3 | PUMP MODEL | | | | | | | | | |
|-----------------------|--------------|------------------------------|--------------------|---|--------------------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 3-12 F M | PVM 3-12 F T | PVM 3-13 F M | PVM 3-13 F T | PVM 3-15 F M | PVM 3-15 F T | PVM 3-17 F M | PVM 3-17 F T | PVM 3-19 F M | PVM 3-19 F T |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 | NUT (TIE ROD LOCKING -) | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc |
| | | | 214 | WASHER | ZBR50780 | 4 pc | | ZBR50790 | 4 pc | ZBR50800 | 4 pc | ZBR50810 | 4 pc | ZBR50820 |
| | | | 339 | ROD | | 4 pc | | | 4 pc | | 4 pc | | 4 pc | |
| | 200 | BOLTS AND SCREWS KIT | 435 | SPACER | ZBR50140 | | | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | |
| | | | 477 | SPACER | | | | | | | | | | |
| | 201 | GASKET KIT | 516 | O-RING | ZBR50070 (EPDM standard) | | | | | | | | | |
| | | | 412 | GASKET | ZBR50080 (Viton) | | | | | | | | | |
| | | | 25 | O-RING (PUMP BODY -) | | | | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) | ZBR51040 | | | | | | | | | |
| | | | 487 | BEARING | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | |
| | | | 479 | SPACER | | | | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | ZBR50050 | | | | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 | CHAMBER (UPPER - WITH DIFFUSER) | ZBR51050 | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | |
| | | | 478 | SPACER | | | | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | ZBR51020 | | | | | | | | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | ZBR50170 | | | | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR50910 1 pc | ZBR50920 1 pc | ZBR50910 1 pc | ZBR50920 1 pc | ZBR50910 1 pc | ZBR50920 1 pc | ZBR30720 1 pc | ZBR50930 1 pc | ZBR30720 1 pc | ZBR50930 1 pc |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | ZBR50220 | | | | | | | | | |
| | | | | | ZBR50230 | | | | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR50560 | 1 pc | ZBR50570 | 1 pc | ZBR50580 | 1 pc | ZBR50590 | 1 pc | ZBR50600 | 1 pc |
| | | | 273 | RING (STOP -) | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | 1 pc |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR50100 | | | | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | ZBR50190 | | | | | | | | | |
| | | | | | ZBR50200 | | | | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | ZBR50120 | | | | | | | | | |
| | | | 414 | GUARD COUPLING | | | | | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 286 | CHAMBER (INTERMEDIATE - W/O DIFFUSER) | ZBR51030 | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | |
| | | | 435 | SPACER | | | | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR50340 | 1 pc | ZBR50350 | 1 pc | ZBR50360 | 1 pc | ZBR50370 | 1 pc | ZBR50380 | 1 pc |
| * | 475 | WEAR RINGS KIT | 276 | RING (GUIDE -) | ZBR50060 | | | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | ZBR50040 | | | | | | | | | |
| | | | 36 | RING (ELASTIC -) | | | | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 | NOZZLE (AIR -) | ZBR50150 | | | | | | | | | |
| | | | 5 | PLUG (FILL -) | | | | | | | | | | |
| | | | 412 | GASKET | | | | | | | | | | |



DRW. DR150007

SPARE-PARTS

Select language English

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PVM 3 | PUMP MODEL | | | | | | | | | |
|-----------------------|--------------|------------------------------|--------------------|---|--------------------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 3-7 F M | PVM 3-7 F T | PVM 3-8 F M | PVM 3-8 F T | PVM 3-9 F M | PVM 3-9 F T | PVM 3-10 F M | PVM 3-10 F T | PVM 3-11 F M | PVM 3-11 F T |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 | NUT (TIE ROD LOCKING -) | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc |
| | | | 214 | WASHER | ZBR50730 | 4 pc | ZBR50740 | 4 pc | ZBR50750 | 4 pc | ZBR50760 | 4 pc | ZBR50770 | 4 pc |
| | | | 339 | ROD | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc |
| | 200 | BOLTS AND SCREWS KIT | 435 | SPACER | ZBR50140 | | | | | | | | | 1 pc |
| | | | 73 | NUT | | | | | | | | | | 1 pc |
| | | | 273 | RING (STOP -) | | | | | | | | | | 1 pc |
| | | | 477 | SPACER | | | | | | | | | | 1 pc |
| | 201 | GASKET KIT | 516 | O-RING | ZBR50070 (EPDM standard) | | | | | | | | | 1 pc |
| | | | 412 | GASKET | ZBR50080 (Viton) | | | | | | | | | 3 pc |
| | | | 25 | O-RING (PUMP BODY -) | | | | | | | | | | 2 pc |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) | ZBR51040 | | | | | | | | | 1 pc |
| | | | 487 | BEARING | | | | | | | | | | 1 pc |
| | | | 21 | IMPELLER | | | | | | | | | | 1 pc |
| | | | 479 | SPACER | | | | | | | | | | 1 pc |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | ZBR50050 | | | | | | | | | 1 pc |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 | CHAMBER (UPPER - WITH DIFFUSER) | ZBR51050 | | | | | | | | | 1 pc |
| | | | 21 | IMPELLER | | | | | | | | | | 1 pc |
| | | | 478 | SPACER | | | | | | | | | | 1 pc |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | ZBR51020 | | | | | | | | | 1 pc |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | ZBR50170 | | | | | | | | | 1 pc |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR21150 1 pc | ZBR21160 1 pc | ZBR21210 1 pc | ZBR50900 1 pc | ZBR21210 1 pc | ZBR50900 1 pc | ZBR21210 1 pc | ZBR50900 1 pc | ZBR50910 1 pc | ZBR50920 1 pc |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | ZBR50210 | | | | | | | | | 4 pc |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR50510 | 1 pc | ZBR50520 | 1 pc | ZBR50530 | 1 pc | ZBR50540 | 1 pc | ZBR50550 | 1 pc |
| | | | 273 | RING (STOP -) | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | 1 pc |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR50090 | 1 pc | ZBR50100 | | | | | | | 1 pc |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | ZBR50180 | 1 pc | ZBR50190 | | | | | | | 1 pc |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | ZBR50120 | | | | | | | | | 4 pc |
| | | | 414 | GUARD COUPLING | | | | | | | | | | 2 pc |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 286 | CHAMBER (INTERMEDIATE - W/O DIFFUSER) | ZBR51030 | | | | | | | | | 1 pc |
| | | | 21 | IMPELLER | | | | | | | | | | 1 pc |
| | | | 435 | SPACER | | | | | | | | | | 1 pc |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR50290 | 1 pc | ZBR50300 | 1 pc | ZBR50310 | 1 pc | ZBR50320 | 1 pc | ZBR50330 | 1 pc |
| * | 475 | WEAR RINGS KIT | 276 | RING (GUIDE -) | ZBR50060 | | | | | | | | | 1 pc |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | 1 pc |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | ZBR50040 | | | | | | | | | 1 pc |
| | | | 36 | RING (ELASTIC -) | | | | | | | | | | 1 pc |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 | NOZZLE (AIR -) | ZBR50150 | | | | | | | | | 1 pc |
| | | | 5 | PLUG (FILL -) | | | | | | | | | | 1 pc |
| | | | 412 | GASKET | | | | | | | | | | 2 pc |



DRW. DR150007

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PUMP MODEL | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--------------------|---|--------------------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 5-2 F M | PVM 5-2 F T | PVM 5-3 F M | PVM 5-3 F T | PVM 5-4 F M | PVM 5-4 F T | PVM 5-5 F M | PVM 5-5 F T | PVM 5-6 F M | PVM 5-6 F T |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 | NUT (TIE ROD LOCKING -) | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc |
| | | | 214 | WASHER | ZBR51710 | 4 pc | ZBR51720 | 4 pc | ZBR51730 | 4 pc | ZBR51740 | 4 pc | ZBR51750 | 4 pc |
| | | | 339 | ROD | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc |
| | 200 | BOLTS AND SCREWS KIT | 435 | SPACER | ZBR51260 | | | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | |
| | | | 477 | SPACER | | | | | | | | | | |
| | 201 | GASKET KIT | 516 | O-RING | ZBR50070 (EPDM standard) | | | | | | | | | |
| | | | 412 | GASKET | ZBR50080 (Viton) | | | | | | | | | |
| | | | 25 | O-RING (PUMP BODY -) | | | | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) | ZBR51210 | | | | | | | | | |
| | | | 487 | BEARING | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | |
| | | | 479 | SPACER | | | | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | ZBR50050 | | | | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 | CHAMBER (UPPER - WITH DIFFUSER) | ZBR51220 | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | |
| | | | 478 | SPACER | | | | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | ZBR51190 | | | | | | | | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | ZBR50170 | | | | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR21130 1 pc | ZBR21140 1 pc | ZBR21150 1 pc | ZBR21160 1 pc | ZBR21150 1 pc | ZBR21160 1 pc | ZBR21210 1 pc | ZBR50900 1 pc | ZBR50910 1 pc | ZBR50920 1 pc |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | ZBR50210 4 pc | | | | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR51480 1 pc | | ZBR51490 1 pc | | ZBR51500 1 pc | | ZBR51510 1 pc | | ZBR51520 1 pc | |
| | | | 273 | RING (STOP -) | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | 1 pc |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR50090 1 pc | | | | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | ZBR50180 1 pc | | | | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | ZBR50120 4 pc | | | | | | | | | |
| | | | 414 | GUARD COUPLING | | | | | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 286 | CHAMBER (INTERMEDIATE - W/O DIFFUSER) | ZBR51200 1 pc | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | |
| | | | 435 | SPACER | | | | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR51290 1 pc | | ZBR51300 1 pc | | ZBR51310 1 pc | | ZBR51320 1 pc | | ZBR51330 1 pc | |
| * | 475 | WEAR RINGS KIT | 276 | RING (GUIDE -) | ZBR51240 1 pc | | | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | ZBR51230 1 pc | | | | | | | | | |
| | | | 36 | RING (ELASTIC -) | | | | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 | NOZZLE (AIR -) | ZBR50150 1 pc | | | | | | | | | |
| | | | 5 | PLUG (FILL -) | | | | | | | | | | |
| | | | 412 | GASKET | | | | | | | | | | |



DRW. DR150007

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PVM 5 | PUMP MODEL | | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--------------------|---|--------------------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 5-14 F T | PVM 5-15 F T | PVM 5-16 F T | PVM 5-18 F T | PVM 5-20 F T | PVM 5-22 F T | PVM 5-24 F T | PVM 5-26 F T | PVM 5-29 F T | PVM 5-32 F T | PVM 5-36 F T | |
| | 82 | TIE ROD KIT (PUMP BODY ~) | 97 | NUT (TIE ROD LOCKING ~) | | | | | | | | | | | | |
| | | | 214 | WASHER | ZBR51830 | ZBR51840 | ZBR51850 | ZBR50860 | ZBR50870 | ZBR51860 | ZBR50890 | ZBR51870 | ZBR51880 | ZBR51890 | ZBR51900 | |
| | | | 339 | ROD | | | | | | | | | | | | |
| | 200 | BOLTS AND SCREWS KIT | 435 | SPACER | ZBR51260 | | | | | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | | | |
| | | | 273 | RING (STOP ~) | | | | | | | | | | | | |
| | | | 477 | SPACER | | | | | | | | | | | | |
| | 201 | GASKET KIT | 516 | O-RING | ZBR50070 (EPDM standard) | | | | | | | | | | | |
| | | | 412 | GASKET | ZBR50080 (Viton) | | | | | | | | | | | |
| | | | 25 | O-RING (PUMP BODY ~) | | | | | | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. ~) | ZBR51210 | | | | | | | | | | | |
| | | | 487 | BEARING | | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | | |
| | | | 479 | SPACER | | | | | | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL ~) | ZBR50050 | | | | | | | | | | | |
| | 323 | STAGE (INTERMEDIATE ~)KIT | 308 | CHAMBER (UPPER ~ WITH DIFFUSER) | ZBR51220 | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | | |
| | | | 478 | SPACER | | | | | | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | ZBR51190 | | | | | | | | | | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP ~) | ZBR50170 | | | | | | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR50950 | ZBR50960 | ZBR47010 | ZBR50970 | | | | | | | | |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | ZBR50230 | ZBR51080 | | | | | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR51600 | ZBR51610 | ZBR51620 | ZBR51630 | ZBR51640 | ZBR51650 | ZBR51660 | ZBR51670 | ZBR51680 | ZBR51690 | ZBR51700 | |
| | | | 273 | RING (STOP ~) | | | | | | | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP ~) | ZBR50110 | ZBR51060 | | | | | | | | | ZBR51250 | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | ZBR50200 | ZBR51070 | | | | | | | | | ZBR51270 | |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | ZBR50130 | | | | | | | | | | | |
| | | | 414 | GUARD COUPLING | | | | | | | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 286 | CHAMBER (INTERMEDIATE ~ W/O DIFFUSER) | ZBR51200 | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | | |
| | | | 435 | SPACER | | | | | | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR51410 | ZBR51420 | ZBR51430 | ZBR50420 | ZBR50430 | ZBR50440 | ZBR50450 | ZBR51440 | ZBR51450 | ZBR51460 | ZBR51470 | |
| * | 475 | WEAR RINGS KIT | 276 | RING (GUIDE ~) | ZBR51240 | | | | | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING ~) | | | | | | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE ~) | ZBR51230 | | | | | | | | | | | |
| | | | 36 | RING (ELASTIC ~) | | | | | | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 | NOZZLE (AIR ~) | ZBR50150 | | | | | | | | | | | |
| | | | 5 | PLUG (FILL ~) | | | | | | | | | | | | |
| | | | 412 | GASKET | | | | | | | | | | | | |



DRW. DR150007

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PVM 5 | PUMP MODEL | | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--------------------|---|-------------|-------------|-------------|-------------|-------------|-------------|--------------|--------------|--------------|--------------|--------------|------|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 5-7 F M | PVM 5-7 F T | PVM 5-8 F M | PVM 5-8 F T | PVM 5-9 F M | PVM 5-9 F T | PVM 5-10 F M | PVM 5-10 F T | PVM 5-11 F T | PVM 5-12 F T | PVM 5-13 F T | |
| | 82 | TIE ROD KIT (PUMP BODY ~) | 97 | NUT (TIE ROD LOCKING ~) | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc |
| | | | 214 | WASHER | ZBR51760 | 4 pc | ZBR51770 | 4 pc | ZBR51780 | 4 pc | ZBR51790 | 4 pc | ZBR51800 | 4 pc | ZBR51810 | 4 pc |
| | | | 339 | ROD | | | | | | | | | | | | |
| | 200 | BOLTS AND SCREWS KIT | 435 | SPACER | | | | | | | | | | | | 1 pc |
| | | | 73 | NUT | | | | | | | | | | | | 1 pc |
| | | | 273 | RING (STOP ~) | | | | | | | | | | | | 1 pc |
| | | | 477 | SPACER | | | | | | | | | | | | 1 pc |
| | 201 | GASKET KIT | 516 | O-RING | | | | | | | | | | | | 1 pc |
| | | | 412 | GASKET | | | | | | | | | | | | 3 pc |
| | | | 25 | O-RING (PUMP BODY ~) | | | | | | | | | | | | 2 pc |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. ~) | | | | | | | | | | | | 1 pc |
| | | | 487 | BEARING | | | | | | | | | | | | 1 pc |
| | | | 21 | IMPELLER | | | | | | | | | | | | 1 pc |
| | | | 479 | SPACER | | | | | | | | | | | | 1 pc |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL ~) | | | | | | | | | | | | 1 pc |
| | 323 | STAGE (INTERMEDIATE ~)KIT | 308 | CHAMBER (UPPER ~ WITH DIFFUSER) | | | | | | | | | | | | 1 pc |
| | | | 21 | IMPELLER | | | | | | | | | | | | 1 pc |
| | | | 478 | SPACER | | | | | | | | | | | | 1 pc |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | | | | | | | | | | | | 1 pc |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP ~) | | | | | | | | | | | | 1 pc |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR50910 | 1 pc | ZBR50920 | 1 pc | ZBR50910 | 1 pc | ZBR50920 | 1 pc | ZBR30720 | 1 pc | ZBR50930 | 1 pc |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | | | | | | | | | | | | 4 pc |
| | | | 232 | SHAFT | | | | | | | | | | | | 1 pc |
| | 404 | SHAFT KIT | 273 | RING (STOP ~) | ZBR51530 | 1 pc | ZBR51540 | 1 pc | ZBR51550 | 1 pc | ZBR51560 | 1 pc | ZBR51570 | 1 pc | ZBR51580 | 1 pc |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP ~) | | | | | | | | | | | | 1 pc |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | | | | | | | | | | | | 1 pc |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | | | | | | | | | | | | 4 pc |
| | | | 414 | GUARD COUPLING | | | | | | | | | | | | 2 pc |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 286 | CHAMBER (INTERMEDIATE ~ W/O DIFFUSER) | | | | | | | | | | | | 1 pc |
| | | | 21 | IMPELLER | | | | | | | | | | | | 1 pc |
| | | | 435 | SPACER | | | | | | | | | | | | 1 pc |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR51340 | 1 pc | ZBR51350 | 1 pc | ZBR51360 | 1 pc | ZBR51370 | 1 pc | ZBR51380 | 1 pc | ZBR51390 | 1 pc |
| * | 475 | WEAR RINGS KIT | 276 | RING (GUIDE ~) | | | | | | | | | | | | 1 pc |
| | | | 277 | SUPPORT (GUIDE RING ~) | | | | | | | | | | | | 1 pc |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE ~) | | | | | | | | | | | | 1 pc |
| | | | 36 | RING (ELASTIC ~) | | | | | | | | | | | | 1 pc |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 | NOZZLE (AIR ~) | | | | | | | | | | | | 1 pc |
| | | | 5 | PLUG (FILL ~) | | | | | | | | | | | | 1 pc |
| | | | 412 | GASKET | | | | | | | | | | | | 2 pc |

| SPARE-PARTS | | | | PUMP MODEL | | | | | | | | | | | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--------------------|---|--------------------------|------|--------------|------|--------------|------|--------------|----------|--------------|------|--------------|------|----------|------|----------|------|----------|------|----------|------|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 10-1 F M | | PVM 10-2 F T | | PVM 10-3 F M | | PVM 10-4 F M | | PVM 10-5 F T | | PVM 10-6 F T | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 | NUT (TIE ROD LOCKING -) | | | | | | | | | | | | | | | | | | | | |
| | | | 214 | WASHER | ZBR52680 | 4 pc | ZBR52690 | 4 pc | ZBR52700 | 4 pc | ZBR52710 | 4 pc | ZBR52720 | 4 pc | ZBR52730 | 4 pc | | | | | | | | |
| | | | 339 | ROD | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | 4 pc | | | | | | | | |
| | 200 | BOLTS AND SCREWS KIT | 435 | SPACER | ZBR52250 | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | | 2 pc | | | | | | | | |
| | | | 476 | BUSHING | | | | | | | | | | | | 1 pc | | | | | | | | |
| | 201 | GASKET KIT | 516 | O-RING | ZBR52140 (EPDM standard) | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 412 | GASKET | ZBR52150 (Viton) | | | | | | | | | | | 3 pc | | | | | | | | |
| | | | 25 | O-RING (PUMP BODY -) | | | | | | | | | | | | 2 pc | | | | | | | | |
| | | | 87 | O-RING (SHUTTER -) | | | | | | | | | | | | 1 pc | | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) | ZBR52090 | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 487 | BEARING | | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 479 | SPACER | | | | | | | | | | | | 1 pc | | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | ZBR52120 | | | | | | | | | | | 1 pc | | | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 | CHAMBER (UPPER - WITH DIFFUSER) | ZBR52110 | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 478 | SPACER | | | | | | | | | | | | 1 pc | | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | ZBR51910 | | | | | | | | | | | 1 pc | | | | | | | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | ZBR52270 | | | | | | | | | | | 1 pc | | | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR21130 | 1 pc | ZBR21140 | 1 pc | ZBR21210 | 1 pc | ZBR50900 | 1 pc | ZBR50910 | 1 pc | ZBR50920 | 1 pc | ZBR30720 | 1 pc | ZBR50930 | 1 pc | ZBR50950 | 1 pc | ZBR50950 | 1 pc |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | ZBR50210 | 4 pc | ZBR50220 | | | | 4 pc | ZBR52240 | | | | | | 4 pc | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR52520 | 1 pc | ZBR52530 | 1 pc | ZBR52540 | 1 pc | ZBR52550 | 1 pc | ZBR52560 | 1 pc | ZBR52570 | 1 pc | | | | | | | | |
| | | | 273 | RING (STOP -) | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | 1 pc | | | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR52160 | 1 pc | ZBR52170 | | | | 1 pc | ZBR52180 | | | | | | 1 pc | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | ZBR52280 | 1 pc | ZBR52290 | | | | 1 pc | ZBR52300 | | | | | | 1 pc | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | ZBR52210 | 4 pc | ZBR52220 | | | | 4 pc | ZBR52230 | | | | | | 4 pc | | | | | | |
| | | | 414 | GUARD COUPLING | | 2 pc | | | | | 2 pc | | | | | | | 2 pc | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 21 | IMPELLER | ZBR51920 | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 435 | SPACER | | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 284 | INTERCONNECTOR (COMPLETE SUCTION -) | | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 249 | ROD GUIDE JIG | | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 485 | SPACER | | | | | | | | | | | | 1 pc | | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR52360 | 1 pc | ZBR52370 | 1 pc | ZBR52380 | 1 pc | ZBR52390 | 1 pc | ZBR52400 | 1 pc | ZBR52410 | 1 pc | | | | | | | | |
| * | 475 | WEAR RINGS KIT | 276 | RING (GUIDE -) | ZBR52130 | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | | 1 pc | | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | ZBR52100 | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 477 | SPACER | | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 228 | GASKET (ANTI-VIBRATION -) | | | | | | | | | | | | 1 pc | | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 | NOZZLE (AIR -) | ZBR50150 | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 5 | PLUG (FILL -) | | | | | | | | | | | | 1 pc | | | | | | | | |
| | | | 412 | GASKET | | | | | | | | | | | | 2 pc | | | | | | | | |



DRW. DR150008

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PVM 10 | PUMP MODEL | | | | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--------------------|---|--------------------------|-------------|-------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--|--|--|--|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 10-7 FT | PVM 10-8 FT | PVM 10-9 FT | PVM 10-10 FT | PVM 10-12 FT | PVM 10-14 FT | PVM 10-16 FT | PVM 10-18 FT | PVM 10-20 FT | PVM 10-22 FT | | | | |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 | NUT (TIE ROD LOCKING -) | | | | | | | | | | | | | | |
| | | | 214 | WASHER | ZBR52740 | ZBR52750 | ZBR52760 | ZBR52770 | ZBR52780 | ZBR52790 | ZBR52800 | ZBR52810 | ZBR52820 | ZBR52830 | | | | |
| | | | 339 | ROD | | | | | | | | | | | | | | |
| | 200 | BOLTS AND SCREWS KIT | 435 | SPACER | ZBR52250 | | | | | | | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | | | | |
| | | | 476 | BUSHING | | | | | | | | | | | | | | |
| | 201 | GASKET KIT | 516 | O-RING | ZBR52140 (EPDM standard) | | | | | | | | | | | | | |
| | | | 412 | GASKET | ZBR52150 (Viton) | | | | | | | | | | | | | |
| | | | 25 | O-RING (PUMP BODY -) | | | | | | | | | | | | | | |
| | | | 87 | O-RING (SHUTTER -) | | | | | | | | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) | ZBR52090 | | | | | | | | | | | | | |
| | | | 487 | BEARING | | | | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | | | | |
| | | | 479 | SPACER | | | | | | | | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | ZBR52120 | | | | | | | | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 | CHAMBER (UPPER - WITH DIFFUSER) | ZBR52110 | | | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | | | | |
| | | | 478 | SPACER | | | | | | | | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | ZBR51910 | | | | | | | | | | | | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | ZBR52270 | | | | | | | | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR50960 | ZBR50960 | ZBR50960 | ZBR47010 | ZBR47010 | ZBR50970 | ZBR50970 | ZBR50980 | ZBR50980 | ZBR50980 | | | | |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | ZBR51080 | | | | ZBR52250 | | | | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR52580 | ZBR52590 | ZBR52600 | ZBR52610 | ZBR52620 | ZBR52630 | ZBR52640 | ZBR52650 | ZBR52660 | ZBR52670 | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR52190 | | | | | | | | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | ZBR52310 | | | | | | | | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | ZBR52230 | | | | | | | | | | | | | |
| | | | 414 | GUARD COUPLING | | | | | | | | | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 21 | IMPELLER | ZBR51920 | | | | | | | | | | | | | |
| | | | 435 | SPACER | | | | | | | | | | | | | | |
| | | | 284 | INTERCONNECTOR (COMPLETE SUCTION -) | | | | | | | | | | | | | | |
| | | | 249 | ROD GUIDE JIG | | | | | | | | | | | | | | |
| | | | 485 | SPACER | | | | | | | | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR52420 | ZBR52430 | ZBR52440 | ZBR52450 | ZBR52460 | ZBR52470 | ZBR52480 | ZBR52490 | ZBR52500 | ZBR52510 | | | | |
| * | 475 | WEAR RINGS KIT | 276 | RING (GUIDE -) | ZBR52130 | | | | | | | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | ZBR52100 | | | | | | | | | | | | | |
| | | | 477 | SPACER | | | | | | | | | | | | | | |
| | | | 228 | GASKET (ANTI-VIBRATION -) | | | | | | | | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 | NOZZLE (AIR -) | ZBR50150 | | | | | | | | | | | | | |
| | | | 5 | PLUG (FILL -) | | | | | | | | | | | | | | |
| | | | 412 | GASKET | | | | | | | | | | | | | | |



DRW. DR150008

SPARE-PARTS

Select language English

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PUMP MODEL | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--------------------------------|--|--|----------|----------|----------|----------|----------|----------|----------|----------|-----------|-----------|-----------|-----------|--------------------------------------|----------|----------|----------|------|----------|----------|----------|------|----------|------|----------|------|----------|------|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | PVM | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | 15-1 F M | 15-1 F T | 15-2 F T | 15-3 F T | 15-4 F T | 15-5 F T | 15-6 F T | 15-7 F T | 15-8 F T | 15-9 F T | 15-10 F T | 15-12 F T | 15-14 F T | 15-17 F T | | | | | | | | | | | | | | | |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 214 339 | NUT (TIE ROD LOCKING -) WASHER ROD | ZBR53350 | 4 pc | ZBR53360 | 4 pc | ZBR53370 | 4 pc | ZBR53380 | 4 pc | ZBR53390 | 4 pc | ZBR53400 | 4 pc | ZBR53410 | 4 pc | ZBR53420 | 4 pc | ZBR53430 | 4 pc | ZBR53440 | 4 pc | ZBR53450 | 4 pc | ZBR53460 | 4 pc | ZBR53470 | 4 pc | | |
| | 200 | BOLTS AND SCREWS KIT | 435 73 273 476 | SPACER NUT RING (STOP -) BUSHING | ZBR52250 | | | | | | | | | | | | | 1 pc | | | | | | | | | | | | | | |
| | 201 | GASKET KIT | 516 412 25 87 | O-RING GASKET O-RING (PUMP BODY -) O-RING (SHUTTER -) | ZBR52140 (EPDM standard) ZBR52150 (Viton) | | | | | | | | | | | | | 1 pc 3 pc 2 pc 1 pc | | | | | | | | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 487 21 479 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) BEARING IMPELLER SPACER | ZBR52990 | | | | | | | | | | | | | 1 pc 1 pc 1 pc 1 pc | | | | | | | | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | ZBR52120 | | | | | | | | | | | | | 1 pc | | | | | | | | | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 21 478 | CHAMBER (UPPER - WITH DIFFUSER) IMPELLER SPACER | ZBR53010 | | | | | | | | | | | | | 1 pc 1 pc 1 pc | | | | | | | | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | ZBR52840 | | | | | | | | | | | | | 1 pc | | | | | | | | | | | | | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | ZBR53040 | | | | | | | | | | | | | 1 pc | | | | | | | | | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR50910 | 1 pc | ZBR50920 | 1 pc | ZBR50950 | 1 pc | ZBR50960 | 1 pc | ZBR47010 | 1 pc | ZBR47010 | 1 pc | ZBR50970 | 1 pc | ZBR50970 | 1 pc | ZBR50980 | 1 pc | ZBR50980 | 1 pc | ZBR50990 | 1 pc | ZBR50990 | 1 pc | ZBR50990 | 1 pc | ZBR51010 | 1 pc |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | ZBR50220 | 4 pc | ZBR53060 | 4 pc | ZBR51080 | 4 pc | ZBR53070 | | | | | | | | | | | | | ZBR53080 | 4 pc | | | | | | | |
| | 404 | SHAFT KIT | 232 273 | SHAFT RING (STOP -) | ZBR53220 | 1 pc | ZBR53230 | 1 pc | ZBR53240 | 1 pc | ZBR53250 | 1 pc | ZBR53260 | 1 pc | ZBR53270 | 1 pc | ZBR53280 | 1 pc | ZBR53290 | 1 pc | ZBR53300 | 1 pc | ZBR53310 | 1 pc | ZBR53320 | 1 pc | ZBR53330 | 1 pc | ZBR53340 | 1 pc | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR52170 | 1 pc | ZBR52180 | 1 pc | ZBR52190 | 1 pc | ZBR52200 | | | | | | | | | | | | | ZBR53030 | 1 pc | | | | | | | |
| | 406 | LANTERN KIT | 27 | LANTERN | ZBR52290 | 1 pc | ZBR52300 | 1 pc | ZBR52310 | 1 pc | ZBR52320 | | | | | | | | | | | | | ZBR53050 | 1 pc | | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 414 | GUARD COUPLING SCREW GUARD COUPLING | ZBR52220 | 4 pc | ZBR52230 | | | | | | | | | | | | | ZBR52240 | 2 pc | | | | | | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 21 435 284 249 485 | IMPELLER SPACER INTERCONNECTOR (COMPLETE SUCTION -) ROD GUIDE JIG SPACER | ZBR52850 | | | | | | | | | | | | | 1 pc 1 pc 1 pc 1 pc 1 pc | | | | | | | | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR53090 | 1 pc | ZBR53100 | 1 pc | ZBR53110 | 1 pc | ZBR53120 | 1 pc | ZBR53130 | 1 pc | ZBR53140 | 1 pc | ZBR53150 | 1 pc | ZBR53160 | 1 pc | ZBR53170 | 1 pc | ZBR53180 | 1 pc | ZBR53190 | 1 pc | ZBR53200 | 1 pc | ZBR53210 | 1 pc | | |
| * | 475 | WEAR RINGS KIT | 276 277 | RING (GUIDE -) SUPPORT (GUIDE RING -) | ZBR53020 | | | | | | | | | | | | | 1 pc 1 pc | | | | | | | | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 477 228 | DIFFUSER (DISCHARGE -) SPACER GASKET (ANTI-VIBRATION -) | ZBR53000 | | | | | | | | | | | | | 1 pc 1 pc 1 pc | | | | | | | | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 5 412 | NOZZLE (AIR -) PLUG (FILL -) GASKET | ZBR50150 | | | | | | | | | | | | | 1 pc 1 pc 2 pc | | | | | | | | | | | | | | |




DRW. DR150008

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PVM 20 | PUMP MODEL | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--------------------------------|--|--|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|---------------|---------------|---------------|---------------|------|----------|------|----------|------|----------|------|----------|------|----------|------|--|--|--|--|--|--|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 20-1 F M | PVM 20-1 F T | PVM 20-2 F T | PVM 20-3 F T | PVM 20-4 F T | PVM 20-5 F T | PVM 20-6 F T | PVM 20-7 F T | PVM 20-8 F T | PVM 20-10 F T | PVM 20-12 F T | PVM 20-14 F T | PVM 20-17 F T | | | | | | | | | | | | | | | | | |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 214 339 | NUT (TIE ROD LOCKING -) WASHER ROD | ZBR53350 | 4 pc | ZBR53360 | 4 pc | ZBR53370 | 4 pc | ZBR53380 | 4 pc | ZBR53390 | 4 pc | ZBR53400 | 4 pc | ZBR53410 | 4 pc | ZBR53420 | 4 pc | ZBR53440 | 4 pc | ZBR53450 | 4 pc | ZBR53460 | 4 pc | ZBR53470 | 4 pc | | | | | | |
| | 200 | BOLTS AND SCREWS KIT | 435 73 273 476 | SPACER NUT RING (STOP -) BUSHING | ZBR52250 | | | | | | | | | | | | 1 pc | 1 pc | 2 pc | 1 pc | | | | | | | | | | | | | | |
| | 201 | GASKET KIT | 516 412 25 87 | O-RING GASKET O-RING (PUMP BODY -) O-RING (SHUTTER -) | ZBR52140 (EPDM standard) ZBR52150 (Viton) | | | | | | | | | | | | 1 pc | 3 pc | 2 pc | 1 pc | | | | | | | | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 487 21 479 | CHAMBER (DIFFUSER-BEARING-RING INTERM. BEARING IMPELLER SPACER | ZBR53500 | | | | | | | | | | | | 1 pc | 1 pc | 1 pc | 1 pc | | | | | | | | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | ZBR52120 | | | | | | | | | | | | 1 pc | | | | | | | | | | | | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 21 478 | CHAMBER (UPPER - WITH DIFFUSER) IMPELLER SPACER | ZBR53510 | | | | | | | | | | | | 1 pc | 1 pc | 1 pc | | | | | | | | | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | ZBR53480 | | | | | | | | | | | | 1 pc | | | | | | | | | | | | | | | | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | ZBR53040 | | | | | | | | | | | | 1 pc | | | | | | | | | | | | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR50910 | 1 pc | ZBR50920 | 1 pc | ZBR50950 | 1 pc | ZBR47010 | 1 pc | ZBR50970 | 1 pc | ZBR50980 | 1 pc | ZBR50990 | 1 pc | ZBR51010 | 1 pc | ZBR47660 | 1 pc | | | | | | | | | | | | |
| | 560 | BOLTS AND SCREWS KIT | 4 | SCREW | ZBR50220 | 4 pc | ZBR53060 | 4 pc | ZBR51080 | 4 pc | ZBR53070 | 4 pc | ZBR53080 | 4 pc | | | | | | | | | | | | | | | | | | | | |
| | 404 | SHAFT KIT | 232 273 | SHAFT RING (STOP -) | ZBR53220 | 1 pc | ZBR53230 | 1 pc | ZBR53240 | 1 pc | ZBR53250 | 1 pc | ZBR53260 | 1 pc | ZBR53270 | 1 pc | ZBR53280 | 1 pc | ZBR53290 | 1 pc | ZBR53310 | 1 pc | ZBR53320 | 1 pc | ZBR53330 | 1 pc | ZBR53340 | 1 pc | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR52170 | 1 pc | ZBR52180 | 1 pc | ZBR52190 | 1 pc | ZBR52200 | 1 pc | ZBR53030 | 1 pc | | | | | | | | | | | | | | | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | ZBR52290 | 1 pc | ZBR52300 | 1 pc | ZBR52310 | 1 pc | ZBR52320 | 1 pc | ZBR53520 | 1 pc | ZBR53050 | 1 pc | ZBR53550 | 1 pc | | | | | | | | | | | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 414 | GUARD COUPLING SCREW GUARD COUPLING | ZBR52210 | 4 pc | ZBR52220 | 2 pc | ZBR52230 | 4 pc | ZBR52240 | 2 pc | | | | | | | | | | | | | | | | | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 21 435 284 249 485 | IMPELLER SPACER INTERCONNECTOR (COMPLETE SUCTION -) ROD GUIDE JIG SPACER | ZBR53490 | | | | | | | | | | | | 1 pc | 1 pc | 1 pc | 1 pc | 1 pc | | | | | | | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR53090 | 1 pc | ZBR53100 | 1 pc | ZBR53110 | 1 pc | ZBR53120 | 1 pc | ZBR53130 | 1 pc | ZBR53140 | 1 pc | ZBR53150 | 1 pc | ZBR53160 | 1 pc | ZBR53180 | 1 pc | ZBR53190 | 1 pc | ZBR53200 | 1 pc | ZBR53210 | 1 pc | | | | | | |
| * | 475 | WEAR RINGS KIT | 276 277 | RING (GUIDE -) SUPPORT (GUIDE RING -) | ZBR53020 | | | | | | | | | | | | 1 pc | 1 pc | | | | | | | | | | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 477 228 | DIFFUSER (DISCHARGE -) SPACER GASKET (ANTI-VIBRATION -) | ZBR53000 | | | | | | | | | | | | 1 pc | 1 pc | 1 pc | | | | | | | | | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 5 412 | NOZZLE (AIR -) PLUG (FILL -) GASKET | ZBR50150 | | | | | | | | | | | | 1 pc | 1 pc | 2 pc | | | | | | | | | | | | | | | |
| | 484 | RECYCLING PLUG KIT | 88 87 412 | SHUTTER O-RING (SHUTTER -) GASKET | ZBR52260 | | | | | | | | | | | | 1 pc | 1 pc | 1 pc | | | | | | | | | | | | | | | |
| | 523 | TIE ROD KIT (HYDRAULIC -) | 522 66 71 | ROD SCREW WASHER | ZBR52860 | 2 pc | ZBR52870 | 2 pc | ZBR52880 | 2 pc | ZBR52890 | 2 pc | ZBR52900 | 2 pc | ZBR52910 | 2 pc | ZBR52920 | 2 pc | ZBR52930 | 2 pc | ZBR52950 | 2 pc | ZBR52960 | 2 pc | ZBR52970 | 2 pc | ZBR52980 | 2 pc | | | | | | |

|  | | DRW. DR150009 | | SPARE-PARTS | | | | | | | | | | | | | | |
|--|------------------------------|--------------------------------------|--|-----------------------|----------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| RECOMMENDED PARTS KIT | | Select language English | | SPARE-PARTS KIT TABLE | | | | | | | | | | | | | | |
| SPARE-PARTS | | PVM 32 | | PUMP MODEL | | | | | | | | | | | | | | |
| KIT REF. No. | KIT DESCRIPTION | COMPONENT NR REF. No. | COMPONENT DESCRIPTION | PVM 32-1-1 F M | PVM 32-1-1 F T | PVM 32-1 F T | PVM 32-2 F T | PVM 32-2 F T | PVM 32-3 F T | PVM 32-3 F T | PVM 32-4 F T | PVM 32-4 F T | PVM 32-5 F T | PVM 32-5 F T | PVM 32-6 F T | PVM 32-6 F T | PVM 32-7 F T | PVM 32-7 F T |
| 82 | THE ROD KIT (PUMP BODY -) | 97 | NUT (THE ROD LOCKING -) | | | | | | | | | | | | | | | |
| | | 214 | WASHER | | ZBR54210 | | ZBR54220 | | ZBR54230 | | ZBR54240 | | ZBR54250 | | ZBR54260 | | ZBR54270 | |
| | | 330 | ROD | | | | | | | | | | | | | | | |
| | | 463 | FLANGE | | | | | | | | | | | | | | | |
| 453 | SUPPORT FLANGE KIT | 36 | RING (ELASTIC -) | | | | | | | | | | | | | | | |
| | | 516 | O-RING | | | | | | | | | | | | | | | |
| | | 412 | GASKET | | | | | | | | | | | | | | | |
| 201 | GASKET KIT | 228 | GASKET (ANTI-VIBRATION -) | | | | | | | | | | | | | | | |
| | | 25 | O-RING (PUMP BODY -) | | | | | | | | | | | | | | | |
| | | 230 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) | | | | | | | | | | | | | | | |
| | | 273 | RING (STOP -) | | | | | | | | | | | | | | | |
| | | 276 | RING (GUIDE -) | | | | | | | | | | | | | | | |
| | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | | | | | |
| | | 487 | BEARING | | | | | | | | | | | | | | | |
| | | 21 | IMPELLER | | | | | | | | | | | | | | | |
| | | 319 | BUSHING (CONIC -) | | | | | | | | | | | | | | | |
| | | 73 | NUT | | | | | | | | | | | | | | | |
| | | 308 | CHAMBER (UPPER - WITH DIFFUSER) | | | | | | | | | | | | | | | |
| | | 273 | RING (STOP -) | | | | | | | | | | | | | | | |
| | | 276 | RING (GUIDE -) | | | | | | | | | | | | | | | |
| | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | | | | | |
| | | 21 | IMPELLER | | | | | | | | | | | | | | | |
| | | 319 | BUSHING (CONIC -) | | | | | | | | | | | | | | | |
| | | 73 | NUT | | | | | | | | | | | | | | | |
| 323 | STAGE (INTERMEDIATE -) KIT | 24 | SEAL (COMPLETE MECHANICAL -) | | | | | | | | | | | | | | | |
| | | 11 | DIFFUSER (DISCHARGE -) | | | | | | | | | | | | | | | |
| | | 21 | IMPELLER | | | | | | | | | | | | | | | |
| | | 577 | REDUCED IMPELLER | | | | | | | | | | | | | | | |
| | | 288 | BASE (PUMP -) | | | | | | | | | | | | | | | |
| 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | | | | | | | | | | | | | | | |
| 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | | | | | | | | | | | | | | | |
| 372 | HYDRAULIC KIT | 21 | IMPELLER | | | | | | | | | | | | | | | |
| 578 | HYDRAULIC KIT | 577 | REDUCED IMPELLER | | | | | | | | | | | | | | | |
| 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | | | | | | | | | | | | | | | |
| 402 | MOTOR KIT | 488 | COMPLETE MOTOR | | | | | | | | | | | | | | | |
| | | 109 | NUT (MOTOR LOCKING -) | | | | | | | | | | | | | | | |
| | | 4 | SCREW | | | | | | | | | | | | | | | |
| | | 107 | SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) | | | | | | | | | | | | | | | |
| | | 71 | WASHER | | | | | | | | | | | | | | | |
| | | 105 | SCREW | | | | | | | | | | | | | | | |
| 404 | SHAFT KIT | 232 | SHAFT | | | | | | | | | | | | | | | |
| | | 106 | WASHER (TOOTHED -) | | | | | | | | | | | | | | | |
| | | 92 | WASHER | | | | | | | | | | | | | | | |
| | | 413 | SCREW | | | | | | | | | | | | | | | |
| | | 478 | BUSHING | | | | | | | | | | | | | | | |
| | | 278 | RING (BEARING -) | | | | | | | | | | | | | | | |
| | | 165 | WASHER (BEARING LOCK -) | | | | | | | | | | | | | | | |
| | | 158 | SCREW (STOP -) | | | | | | | | | | | | | | | |
| 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | | | | | | | | | | | | | | | |
| 356 | MOTOR COMPLETE KIT | 289 | MOTOR (COMPLETE - W / IMPELLER) | | | | | | | | | | | | | | | |
| | | 228 | GASKET (ANTI-VIBRATION -) | | | | | | | | | | | | | | | |
| | | 27 | LANTERN | | | | | | | | | | | | | | | |
| 406 | MOTOR STOOL KIT | 107 | SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) | | | | | | | | | | | | | | | |
| | | 274 | GUARD COUPLING SCREW | | | | | | | | | | | | | | | |
| 411 | GUARD COUPLING KIT | 414 | GUARD COUPLING | | | | | | | | | | | | | | | |
| | | 21 | IMPELLER | | | | | | | | | | | | | | | |
| | | 273 | RING (STOP -) | | | | | | | | | | | | | | | |
| | | 276 | RING (GUIDE -) | | | | | | | | | | | | | | | |
| | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | | | | | |
| | | 319 | BUSHING (CONIC -) | | | | | | | | | | | | | | | |
| | | 73 | NUT | | | | | | | | | | | | | | | |
| | | 284 | INTERCONNECTOR (COMPLETE SUCTION -) | | | | | | | | | | | | | | | |
| 474 | SLEEVE KIT | 83 | SLEEVE | | | | | | | | | | | | | | | |
| | | 276 | RING (GUIDE -) | | | | | | | | | | | | | | | |
| | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | | | | | |
| | | 273 | RING (STOP -) | | | | | | | | | | | | | | | |
| | | 78 | NOZZLE (AIR -) | | | | | | | | | | | | | | | |
| | | 5 | PLUGS (FILL -) | | | | | | | | | | | | | | | |
| | | 522 | ROD | | | | | | | | | | | | | | | |
| | | 66 | SCREW | | | | | | | | | | | | | | | |
| | | 92 | WASHER | | | | | | | | | | | | | | | |
| 523 | THE ROD KIT (PUMP BODY -) | 66 | SCREW | | | | | | | | | | | | | | | |
| | | 92 | WASHER | | | | | | | | | | | | | | | |



DRW. DR150009

Select language English

SPARE-PARTS

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PUMP MODEL | | | | | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--|---|----------------|--------------|----------------|--------------|-----------------|---------------|---|---------------|-----------------|---------------|-----------------|---------------|-----------------|---------------|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 32-8-2 F T | PVM 32-8 F T | PVM 32-9-2 F T | PVM 32-9 F T | PVM 32-10-2 F T | PVM 32-10 F T | PVM 32-11-2 F T | PVM 32-11 F T | PVM 32-12-2 F T | PVM 32-12 F T | PVM 32-13-2 F T | PVM 32-13 F T | PVM 32-14-2 F T | PVM 32-14 F T |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 214 339 | NUT (TIE ROD LOCKING -) WASHER ROD | ZBR54280 | | ZBR54290 | | ZBR54300 | | ZBR54310 | | ZBR54320 | | ZBR54330 | | ZBR54340 | |
| | 453 | SUPPORT FLANGE KIT | 463 36 | FLANGE RING (ELASTIC -) | | | | | | | ZBR53920 | | | | | | | |
| | 201 | GASKET KIT | 516 412 228 25 | O-RING GASKET GASKET (ANTI-VIBRATION -) O-RING (PUMP BODY -) | | | | | | | ZBR53650 (EPDM standard) | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 273 276 277 487 21 319 73 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) BEARING IMPELLER BUSHING (CONIC -) NUT | | | | | | | ZBR53610 (with Standard impeller) ZBR54510 (with reduced impeller) | | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 273 276 277 21 319 73 | CHAMBER (UPPER - WITH DIFFUSER) RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) IMPELLER BUSHING (CONIC -) NUT | | | | | | | ZBR53600 (with Standard impeller) ZBR54500 (with reduced impeller) | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | | | | | | | ZBR53630 | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | | | | | | | ZBR53620 | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | | | | | | | ZBR53570 | | | | | | | |
| | 578 | HYDRAULIC KIT | 577 | REDUCED IMPELLER | ZBR53580 | - | ZBR53580 | - | ZBR53580 | - | ZBR53580 | - | ZBR53580 | - | ZBR53580 | - | ZBR53580 | - |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | | | | | | | ZBR53900 | | | | | | | |
| | 402 | MOTOR KIT | 488 109 | COMPLETE MOTOR NUT (MOTOR LOCKING -) | ZBR51010 | | ZBR47660 | | ZBR51000 | | ZBR51180 | | | | | | | |
| | 560 | BOLTS AND SCREWS KIT | 4 107 71 105 | SCREW SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) WASHER SCREW | | | | | | | ZBR53840 | | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR54140 | | ZBR54150 | | ZBR54160 | | ZBR54170 | | ZBR54180 | | ZBR54190 | | ZBR54200 | |
| | 341 | BEARING KIT | 108 92 413 476 278 165 158 | WASHER (TOOTHED -) WASHER SCREW BUSHING RING (BEARING -) WASHER (BEARING LOCK -) SCREW (STOP -) | | | | | | | ZBR53910 | | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | | | ZBR53750 | | ZBR53760 | | ZBR53770 | | | | | | | |
| | 356 | MOTOR COMPLETE KIT | 289 228 | MOTOR (COMPLETE - W / IMPELLER) GASKET (ANTI-VIBRATION -) | | | | | | | ZBR53800 | | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 107 | LANTERN SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) | | | | | ZBR53880 | | ZBR53890 | | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 414 | GUARD COUPLING SCREW GUARD COUPLING | | | | | | | ZBR53790 | | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 21 273 276 277 319 73 284 | IMPELLER RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) BUSHING (CONIC -) NUT INTERCONNECTOR (COMPLETE SUCTION -) | | | | | | | ZBR53590 (with Standard impeller) ZBR54490 (with reduced impeller) | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR54000 | | ZBR54010 | | ZBR54020 | | ZBR54030 | | ZBR54040 | | ZBR54050 | | ZBR54060 | |
| * | 475 | WEAR RINGS KIT | 276 277 273 | RING (GUIDE -) SUPPORT (GUIDE RING -) RING (STOP -) | | | | | | | ZBR53640 | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 5 | NOZZLE (AIR -) PLUG (FILL -) | | | | | | | ZBR53660 | | | | | | | |
| | 523 | TIE ROD KIT (PUMP BODY -) | 522 66 92 | ROD SCREW WASHER | ZBR54420 | | ZBR54430 | | ZBR54440 | | ZBR54450 | | ZBR54460 | | ZBR54470 | | ZBR54480 | |



DRW. DR150009

SPARE-PARTS

Select language English

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PVM 45 | PUMP MODEL | | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--|---|---|--------------|----------------|--------------|----------------|--------------|----------------|--------------|----------------|--------------|----------------|--------------|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 45-1-1 F T | PVM 45-1 F T | PVM 45-2-2 F T | PVM 45-2 F T | PVM 45-3-2 F T | PVM 45-3 F T | PVM 45-4-2 F T | PVM 45-4 F T | PVM 45-5-2 F T | PVM 45-5 F T | PVM 45-6-2 F T | PVM 45-6 F T |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 214 339 | NUT (TIE ROD LOCKING -) WASHER ROD | ZBR54970 | | ZBR54980 | | ZBR54990 | | ZBR55000 | | ZBR55010 | | ZBR55020 | |
| | 453 | SUPPORT FLANGE KIT | 463 36 | FLANGE RING (ELASTIC -) | ZBR54700 | | | | | | | | | | | |
| | 201 | GASKET KIT | 516 412 228 25 | O-RING GASKET GASKET (ANTI-VIBRATION -) O-RING (PUMP BODY -) | ZBR54620 (EPDM standard) | | | | | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 273 276 277 487 21 319 73 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) BEARING IMPELLER BUSHING (CONIC -) NUT | ZBR54580 (with Standard impeller) ZBR54590 (with reduced impeller) | | | | | | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 273 276 277 21 319 73 | CHAMBER (UPPER - WITH DIFFUSER) RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) IMPELLER BUSHING (CONIC -) NUT | ZBR54560 (with Standard impeller) ZBR54570 (with reduced impeller) | | | | | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | ZBR53630 | | | | | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | ZBR54600 | | | | | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | | ZBR54520 | | | | ZBR54520 | | | | | | |
| | 578 | HYDRAULIC KIT | 577 | REDUCED IMPELLER | ZBR54530 | | ZBR54530 | | ZBR54530 | | ZBR54530 | | ZBR54530 | | ZBR54530 | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | ZBR54690 | | | | | | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR50960 | ZBR47010 | ZBR50970 | ZBR50980 | ZBR50990 | ZBR51010 | ZBR47660 | ZBR51000 | | | | |
| | 560 | BOLTS AND SCREWS KIT | 109 4 107 71 105 | NUT (MOTOR LOCKING -) SCREW SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) WASHER SCREW | ZBR54650 | | ZBR54660 | | ZBR54670 | | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR54840 | | ZBR54850 | | ZBR54860 | ZBR54870 | ZBR54880 | ZBR54890 | | | | |
| | 341 | BEARING KIT | 108 92 413 476 278 165 158 | WASHER (TOOTHED -) WASHER SCREW BUSHING RING (BEARING -) WASHER (BEARING LOCK -) SCREW (STOP -) | ZBR53910 | | | | | | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR53730 | | ZBR53740 | | ZBR53750 | | ZBR53760 | | | | | |
| | 356 | MOTOR COMPLETE KIT | 289 228 | MOTOR (COMPLETE - W / IMPELLER) GASKET (ANTI-VIBRATION -) | ZBR54640 | | | | | | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 107 | LANTERN SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) | ZBR53860 | | ZBR53870 | | ZBR53880 | | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 414 | GUARD COUPLING SCREW GUARD COUPLING | ZBR53780 | | | | | | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 21 273 276 277 319 73 284 | IMPELLER RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) BUSHING (CONIC -) NUT INTERCONNECTOR (COMPLETE SUCTION -) | ZBR54540 (with Standard impeller) ZBR54550 (with reduced impeller) | | | | | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR54710 | ZBR54720 | ZBR54730 | ZBR54740 | ZBR54750 | ZBR54760 | | | | | | |
| * | 475 | WEAR RINGS KIT | 276 277 273 | RING (GUIDE -) SUPPORT (GUIDE RING -) RING (STOP -) | ZBR54610 | | | | | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 5 | NOZZLE (AIR -) PLUG (FILL -) | ZBR53660 | | | | | | | | | | | |
| | 523 | TIE ROD KIT (PUMP BODY -) | 522 66 92 | ROD SCREW WASHER | ZBR55210 | ZBR55220 | ZBR55230 | ZBR55240 | ZBR55250 | ZBR55260 | | | | | | |



DRW. DR150009

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PUMP MODEL | | | | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--|---|----------------|--------------|----------------|--------------|----------------|--------------|---|---------------|-----------------|---------------|-----------------|---------------|-----------------|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 45-7-2 F T | PVM 45-7 F T | PVM 45-8-2 F T | PVM 45-8 F T | PVM 45-9-2 F T | PVM 45-9 F T | PVM 45-10-2 F T | PVM 45-10 F T | PVM 45-11-2 F T | PVM 45-11 F T | PVM 45-12-2 F T | PVM 45-12 F T | PVM 45-13-2 F T |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 214 339 | NUT (TIE ROD LOCKING -) WASHER ROD | ZBR55030 | | ZBR55040 | | ZBR55050 | | ZBR55060 | | ZBR55070 | | ZBR55080 | | ZBR55200 |
| | 453 | SUPPORT FLANGE KIT | 463 | FLANGE | | | | | | | ZBR54700 | | | | | | |
| | 201 | GASKET KIT | 36 516 412 228 25 | RING (ELASTIC -) O-RING GASKET GASKET (ANTI-VIBRATION -) O-RING (PUMP BODY -) | | | | | | | ZBR54620 (EPDM standard) | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 273 276 277 487 21 319 73 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) BEARING IMPELLER BUSHING (CONIC -) NUT | | | | | | | ZBR54580 (with Standard impeller) ZBR54590 (with reduced impeller) | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 273 276 277 21 319 73 | CHAMBER (UPPER - WITH DIFFUSER) RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) IMPELLER BUSHING (CONIC -) NUT | | | | | | | ZBR54560 (with Standard impeller) ZBR54570 (with reduced impeller) | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | | | | | | | ZBR53630 | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | | | | | | | ZBR54600 | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | | | | | | | ZBR54520 | | | | | | |
| | 578 | HYDRAULIC KIT | 577 | REDUCED IMPELLER | ZBR54530 | - | ZBR54530 | - | ZBR54530 | - | ZBR54530 | - | ZBR54530 | - | ZBR54530 | - | ZBR54530 |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | | | | | | | ZBR54690 | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | | | ZBR51180 | | | | ZBR55340 | | | | ZBR55350 | | |
| | 560 | BOLTS AND SCREWS KIT | 109 4 107 71 105 | NUT (MOTOR LOCKING -) SCREW SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) WASHER SCREW | | | | | | | ZBR54670 | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR54900 | | ZBR54910 | | ZBR54920 | | ZBR54930 | | ZBR54940 | | ZBR54950 | | ZBR54960 |
| | 341 | BEARING KIT | 108 92 413 476 278 165 158 | WASHER (TOOTHED -) WASHER SCREW BUSHING RING (BEARING -) WASHER (BEARING LOCK -) SCREW (STOP -) | | | | | | | ZBR53910 | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | | | | | | | ZBR54630 | | | | | | |
| | 356 | MOTOR COMPLETE KIT | 289 228 | MOTOR (COMPLETE - W / IMPELLER) GASKET (ANTI-VIBRATION -) | | | | | | | ZBR54640 | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 107 | LANTERN SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) | | | ZBR53890 | | | | | | ZBR54680 | | | | |
| | 411 | GUARD COUPLING KIT | 274 414 | GUARD COUPLING SCREW GUARD COUPLING | | | | | | | ZBR53790 | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 21 273 276 277 319 73 284 | IMPELLER RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) BUSHING (CONIC -) NUT INTERCONNECTOR (COMPLETE SUCTION -) | | | | | | | ZBR54540 (with Standard impeller) ZBR54550 (with reduced impeller) | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR54770 | | ZBR54780 | | ZBR54790 | | ZBR54800 | | ZBR54810 | | ZBR54820 | | ZBR54830 |
| * | 475 | WEAR RINGS KIT | 276 277 273 | RING (GUIDE -) SUPPORT (GUIDE RING -) RING (STOP -) | | | | | | | ZBR54610 | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 5 | NOZZLE (AIR -) PLUG (FILL -) | | | | | | | ZBR53660 | | | | | | |
| | 523 | TIE ROD KIT (PUMP BODY -) | 522 66 92 | ROD SCREW WASHER | ZBR55270 | | ZBR55280 | | ZBR55290 | | ZBR55300 | | ZBR55310 | | ZBR55320 | | ZBR55330 |



DRW. DR150009

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PVM 64 | PUMP MODEL | | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--|---|----------------|----------------------|----------------|----------------|----------------------|---|----------------|----------------------|----------------|----------------|--|------|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 64-1-1 F T | PVM 64-1 F T | PVM 64-2-2 F T | PVM 64-2-1 F T | PVM 64-2 F T | PVM 64-3-2 F T | PVM 64-3-1 F T | PVM 64-3 F T | PVM 64-4-2 F T | PVM 64-4-1 F T | PVM 64-4 F T | |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 214 339 | NUT (TIE ROD LOCKING -) WASHER ROD | ZBR55370 | 4 pc 4 pc 4 pc | | ZBR55380 | 4 pc 4 pc 4 pc | | ZBR55390 | 4 pc 4 pc 4 pc | | ZBR55400 | 4 pc 4 pc 4 pc | |
| | 453 | SUPPORT FLANGE KIT | 463 36 | FLANGE RING (ELASTIC -) | | | | | | ZBR55450 | | | | | 2 pc 2 pc | |
| | 201 | GASKET KIT | 516 412 228 25 | O-RING GASKET GASKET (ANTI-VIBRATION -) O-RING (PUMP BODY -) | | | | | | ZBR54620 (EPDM standard) | | | | | 1 pc 6 pc 4 pc 2 pc | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 273 276 277 487 21 319 73 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) BEARING IMPELLER BUSHING (CONIC -) NUT | | | | | | ZBR55460 (with Standard impeller) ZBR55470 (with reduced impeller) | | | | | 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 273 276 277 21 319 73 | CHAMBER (UPPER - WITH DIFFUSER) RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) IMPELLER BUSHING (CONIC -) NUT | | | | | | ZBR55480 (with Standard impeller) ZBR55490 (with reduced impeller) | | | | | 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | | | | | | ZBR53630 | | | | | 1 pc | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | | | | | | ZBR55500 | | | | | 1 pc | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | | | | | | ZBR55510 | | | | | 1 pc | |
| | 578 | HYDRAULIC KIT | 577 | REDUCED IMPELLER | ZBR55520 | 1 pc | - | ZBR55520 | 1 pc | - | ZBR55520 | 1 pc | - | ZBR55520 | 1 pc | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | | | | | | ZBR55530 | | | | | 1 pc | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR47010 | 1 pc | ZBR50970 | 1 pc | ZBR50980 | 1 pc | ZBR50990 | 1 pc | ZBR51010 | 1 pc | ZBR47660 | 1 pc |
| | 560 | BOLTS AND SCREWS KIT | 109 4 107 71 105 | NUT (MOTOR LOCKING -) SCREW SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) WASHER SCREW | ZBR54650 | 4 pc 4 pc | ZBR54660 | 4 pc | | | | | ZBR54670 | | 4 pc 4 pc | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR55540 | 1 pc | | ZBR55550 | 1 pc | | ZBR55560 | 1 pc | | ZBR55570 | 1 pc | |
| | 341 | BEARING KIT | 108 92 413 476 278 165 158 | WASHER (TOOTHED -) WASHER SCREW BUSHING RING (BEARING -) WASHER (BEARING LOCK -) SCREW (STOP -) | | | | | | ZBR53910 | | | | | 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR53730 | 1 pc | ZBR53740 | 1 pc | | ZBR53750 | | | | ZBR53760 | 1 pc | |
| | 356 | MOTOR COMPLETE KIT | 289 228 | MOTOR (COMPLETE - W / IMPELLER) GASKET (ANTI-VIBRATION -) | | | | | | ZBR54640 | | | | | 1 pc 4 pc | |
| | 406 | MOTOR STOOL KIT | 27 107 | LANTERN SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) | ZBR53860 | 1 pc 4 pc | ZBR53870 | 1 pc 4 pc | | | ZBR53880 | | | | 1 pc 4 pc | |
| | 411 | GUARD COUPLING KIT | 274 414 | GUARD COUPLING SCREW GUARD COUPLING | | | ZBR53780 | 4 pc 2 pc | | | ZBR53790 | | | | 4 pc 2 pc | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 21 273 276 277 319 73 284 | IMPELLER RING (STOP -) RING (GUIDE -) SUPPORT (GUIDE RING -) BUSHING (CONIC -) NUT INTERCONNECTOR (COMPLETE SUCTION -) | | | | | | ZBR55620 (with Standard impeller) ZBR55630 (with reduced impeller) | | | | | 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc 1 pc | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR55640 | 1 pc | | ZBR55650 | 1 pc | | ZBR55660 | 1 pc | | ZBR55670 | 1 pc | |
| * | 475 | WEAR RINGS KIT | 276 277 273 | RING (GUIDE -) SUPPORT (GUIDE RING -) RING (STOP -) | | | | | | ZBR55720 | | | | | 1 pc 1 pc 1 pc | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 5 | NOZZLE (AIR -) PLUG (FILL -) | | | | | | ZBR53660 | | | | | 1 pc 5 pc | |
| | 523 | TIE ROD KIT (PUMP BODY -) | 522 66 92 | ROD SCREW WASHER | ZBR55730 | 2 pc 2 pc 2 pc | | ZBR55740 | 2 pc 2 pc 2 pc | | ZBR55750 | 2 pc 2 pc 2 pc | | ZBR55760 | 2 pc 2 pc 2 pc | |



DRW. DR150009

SPARE-PARTS

Select language

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | | PVM 64 | PUMP MODEL | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--------------------|--|---------------|---------------|-------------|---------------|---------------|-----------------------------------|---------------|---------------|-------------|---------------|---------------|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 64-5-2 FT | PVM 64-5-1 FT | PVM 64-5 FT | PVM 64-6-2 FT | PVM 64-6-1 FT | PVM 64-6 FT | PVM 64-7-2 FT | PVM 64-7-1 FT | PVM 64-7 FT | PVM 64-8-2 FT | PVM 64-8-1 FT |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 | NUT (TIE ROD LOCKING -) | | | 4 pc | | | 4 pc | | | 4 pc | | 4 pc |
| | | | 214 | WASHER | ZBR55410 | | | | ZBR55420 | | | | ZBR55430 | | ZBR55440 |
| | | | 339 | ROD | | | | | | | | | | | |
| | 453 | SUPPORT FLANGE KIT | 463 | FLANGE | | | | | | ZBR55450 | | | | | |
| | | | 36 | RING (ELASTIC -) | | | | | | | | | | | |
| | | | 516 | O-RING | | | | | | | | | | | |
| | 201 | GASKET KIT | 412 | GASKET | | | | | | ZBR54620 (EPDM standard) | | | | | |
| | | | 228 | GASKET (ANTI-VIBRATION -) | | | | | | | | | | | |
| | | | 25 | O-RING (PUMP BODY -) | | | | | | | | | | | |
| | | | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) | | | | | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | |
| | | | 276 | RING (GUIDE -) | | | | | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 487 | BEARING | | | | | | ZBR55460 (with Standard impeller) | | | | | |
| | | | 21 | IMPELLER | | | | | | ZBR55470 (with reduced impeller) | | | | | |
| | | | 319 | BUSHING (CONIC -) | | | | | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | | |
| | | | 308 | CHAMBER (UPPER - WITH DIFFUSER) | | | | | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | |
| | | | 276 | RING (GUIDE -) | | | | | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | |
| | | | 319 | BUSHING (CONIC -) | | | | | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | | | | | | ZBR53630 | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | | | | | | ZBR55500 | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | | | | | | ZBR55510 | | | | | |
| | 578 | HYDRAULIC KIT | 577 | REDUCED IMPELLER | ZBR55520 | 1 pc | - | ZBR55520 | 1 pc | - | ZBR55520 | 1 pc | - | ZBR55520 | 1 pc |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | | | | | | ZBR55530 | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR51180 | 1 pc | | | | ZBR55340 | 1 pc | | | ZBR55350 | 1 pc |
| | | | 109 | NUT (MOTOR LOCKING -) | | | | | | | | | | | |
| | | | 4 | SCREW | | | | | | | | | | | |
| | 560 | BOLTS AND SCREWS KIT | 107 | VITE FISSAGGIO MOTORE/SUPPORTO INT. | | | | | | ZBR54670 | | | | | |
| | | | 71 | WASHER | | | | | | | | | | | |
| | | | 105 | SCREW | | | | | | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR55580 | 1 pc | | ZBR55590 | 1 pc | | ZBR55600 | 1 pc | | ZBR55610 | 1 pc |
| | | | 108 | WASHER (TOOTHED -) | | | | | | | | | | | |
| | | | 92 | WASHER | | | | | | | | | | | |
| | | | 413 | SCREW | | | | | | | | | | | |
| | | | 476 | BUSHING | | | | | | ZBR53910 | | | | | |
| | | | 278 | RING (BEARING -) | | | | | | | | | | | |
| | | | 165 | WASHER (BEARING LOCK -) | | | | | | | | | | | |
| | | | 158 | SCREW (STOP -) | | | | | | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | | | | | | ZBR54630 | | | | | |
| | 356 | MOTOR COMPLETE KIT | 289 | MOTOR (COMPLETE - W / IMPELLER) | | | | | | ZBR54640 | | | | | |
| | | | 228 | GASKET (ANTI-VIBRATION -) | | | | | | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | | | | | | | | | | | |
| | | | 107 | SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) | ZBR53890 | | | 1 pc | | | ZBR54680 | | | | |
| | | | 107 | SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) | | | | 4 pc | | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | | | | | | ZBR53790 | | | | | |
| | | | 414 | GUARD COUPLING | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | |
| | | | 276 | RING (GUIDE -) | | | | | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | |
| | | | 319 | BUSHING (CONIC -) | | | | | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | | |
| | | | 284 | INTERCONNECTOR (COMPLETE SUCTION -) | | | | | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR55680 | 1 pc | | ZBR55690 | 1 pc | | ZBR55700 | 1 pc | | ZBR55710 | 1 pc |
| | | | 276 | RING (GUIDE -) | | | | | | | | | | | |
| * | 475 | WEAR RINGS KIT | 277 | SUPPORT (GUIDE RING -) | | | | | | ZBR55720 | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 | NOZZLE (AIR -) | | | | | | ZBR53660 | | | | | |
| | | | 5 | PLUG (FILL -) | | | | | | | | | | | |
| | | | 522 | ROD | | | | | | | | | | | |
| | 523 | TIE ROD KIT (PUMP BODY -) | 66 | SCREW | ZBR55770 | | | | | ZBR55780 | | | | ZBR55790 | |
| | | | 92 | WASHER | | | | | | | | | | ZBR55800 | |



DRW. DR150009

SPARE-PARTS

Select language English

SPARE-PARTS KIT TABLE

| SPARE-PARTS | | | PVM 90 | | PUMP MODEL | | | | | | | | | | | | |
|-----------------------|--------------|------------------------------|--------------------|--|---|--------------|----------------|--------------|----------------|--------------|----------------|--------------|----------------|--------------|----------------|--------------|--|
| RECOMMENDED PARTS KIT | KIT REF. Nr. | KIT DESCRIPTION | COMPONENT REF. Nr. | COMPONENT DESCRIPTION | PVM 90-1-1 F T | PVM 90-1 F T | PVM 90-2-2 F T | PVM 90-2 F T | PVM 90-3-2 F T | PVM 90-3 F T | PVM 90-4-2 F T | PVM 90-4 F T | PVM 90-5-2 F T | PVM 90-5 F T | PVM 90-6-2 F T | PVM 90-6 F T | |
| | 82 | TIE ROD KIT (PUMP BODY -) | 97 | NUT (TIE ROD LOCKING -) | | | | | | | | | | | | | |
| | | | 214 | WASHER | ZBR55820 | | ZBR55830 | | ZBR55840 | | ZBR55850 | | ZBR55860 | | ZBR55870 | | |
| | | | 339 | ROD | | | | | | | | | | | | | |
| | 453 | SUPPORT FLANGE KIT | 463 | FLANGE | ZBR55450 | | | | | | | | | | | | |
| | | | 36 | RING (ELASTIC -) | | | | | | | | | | | | | |
| | 201 | GASKET KIT | 516 | O-RING | ZBR55900 (EPDM standard) | | | | | | | | | | | | |
| | | | 412 | GASKET | | | | | | | | | | | | | |
| | | | 228 | GASKET (ANTI-VIBRATION -) | | | | | | | | | | | | | |
| | | | 25 | O-RING (PUMP BODY -) | | | | | | | | | | | | | |
| | 374 | HYDRAULIC KIT WITH BEARING | 290 | CHAMBER (DIFFUSER-BEARING-RING INTERM. -) | ZBR55880 (with Standard impeller) ZBR55890 (with reduced impeller) | | | | | | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | | | |
| | | | 276 | RING (GUIDE -) | | | | | | | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | | | |
| | | | 487 | BEARING | | | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | | | |
| | | | 319 | BUSHING (CONIC -) | | | | | | | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | | | | |
| | 323 | STAGE (INTERMEDIATE -)KIT | 308 | CHAMBER (UPPER - WITH DIFFUSER) | ZBR55910 (with Standard impeller) ZBR55920 (with reduced impeller) | | | | | | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | | | |
| | | | 276 | RING (GUIDE -) | | | | | | | | | | | | | |
| | | | 277 | SUPPORT (GUIDE RING -) | | | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | | | |
| | | | 319 | BUSHING (CONIC -) | | | | | | | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | | | | |
| | 371 | MECHANICAL SEAL KIT | 24 | SEAL (COMPLETE MECHANICAL -) | ZBR53630 | | | | | | | | | | | | |
| | 373 | HYDRAULIC KIT, LAST STAGE | 11 | DIFFUSER (DISCHARGE -) | ZBR55930 | | | | | | | | | | | | |
| | 372 | HYDRAULIC KIT | 21 | IMPELLER | | ZBR55940 | | | | ZBR55940 | | | | | | | |
| | 578 | HYDRAULIC KIT | 577 | REDUCED IMPELLER | ZBR55950 | | ZBR55950 | | ZBR55950 | | ZBR55950 | | ZBR55950 | | ZBR55950 | | |
| | 384 | PUMP BODY KIT | 288 | BASE (PUMP -) | ZBR55960 | | | | | | | | | | | | |
| | 402 | MOTOR KIT | 488 | COMPLETE MOTOR | ZBR50970 | ZBR50980 | ZBR50990 | ZBR51010 | ZBR47660 | ZBR51000 | ZBR51180 | ZBR55340 | ZBR55350 | | | | |
| | | | 109 | NUT (MOTOR LOCKING -) | | | | | | | | | | | | | |
| | | | 4 | SCREW | | | | | | | | | | | | | |
| | 560 | BOLTS AND SCREWS KIT | 107 | SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) | ZBR53830 | | | | | | | | | | | ZBR53840 | |
| | | | 71 | WASHER | | | | | | | | | | | | | |
| | | | 105 | SCREW | | | | | | | | | | | | | |
| | 404 | SHAFT KIT | 232 | SHAFT | ZBR55970 | ZBR55980 | ZBR55990 | ZBR56000 | ZBR56010 | ZBR56020 | | | | | | | |
| | | | 108 | WASHER (TOOTHED -) | | | | | | | | | | | | | |
| | | | 92 | WASHER | | | | | | | | | | | | | |
| | 341 | BEARING KIT | 413 | SCREW | ZBR53910 | | | | | | | | | | | | |
| | | | 476 | BUSHING | | | | | | | | | | | | | |
| | | | 278 | RING (BEARING -) | | | | | | | | | | | | | |
| | | | 165 | WASHER (BEARING LOCK -) | | | | | | | | | | | | | |
| | | | 158 | SCREW (STOP -) | | | | | | | | | | | | | |
| | 405 | COUPLING KIT | 103 | COUPLING (MOTOR PUMP -) | ZBR53740 | ZBR53750 | ZBR53760 | ZBR54630 | | | | | | | | | |
| | 356 | MOTOR COMPLETE KIT | 289 | MOTOR (COMPLETE - W / IMPELLER) | ZBR56030 | | | | | | | | | | | | |
| | | | 228 | GASKET (ANTI-VIBRATION -) | | | | | | | | | | | | | |
| | 406 | MOTOR STOOL KIT | 27 | LANTERN | ZBR53870 | ZBR53880 | ZBR53890 | ZBR54680 | | | | | | | | | |
| | | | 107 | SCREW (MOTOR LOCKING - / INTERNAL SUPPORT) | | | | | | | | | | | | | |
| | 411 | GUARD COUPLING KIT | 274 | GUARD COUPLING SCREW | ZBR53780 | ZBR53790 | | | | | | | | | | | |
| | | | 414 | GUARD COUPLING | | | | | | | | | | | | | |
| | | | 21 | IMPELLER | | | | | | | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | | | |
| | | | 276 | RING (GUIDE -) | | | | | | | | | | | | | |
| | 452 | HYDRAULIC KIT, FIRST STAGE | 277 | SUPPORT (GUIDE RING -) | ZBR56040 (with Standard impeller) ZBR56050 (with reduced impeller) | | | | | | | | | | | | |
| | | | 319 | BUSHING (CONIC -) | | | | | | | | | | | | | |
| | | | 73 | NUT | | | | | | | | | | | | | |
| | | | 284 | INTERCONNECTOR (COMPLETE SUCTION -) | | | | | | | | | | | | | |
| | 474 | SLEEVE KIT | 83 | SLEEVE | ZBR56060 | ZBR56070 | ZBR56080 | ZBR56090 | ZBR56100 | ZBR56110 | | | | | | | |
| | | | 276 | RING (GUIDE -) | | | | | | | | | | | | | |
| * | 475 | WEAR RINGS KIT | 277 | SUPPORT (GUIDE RING -) | ZBR56120 | | | | | | | | | | | | |
| | | | 273 | RING (STOP -) | | | | | | | | | | | | | |
| | 392 | PLUGS WITH ORING KIT (KIT-B) | 78 | NOZZLE (AIR -) | ZBR53660 | | | | | | | | | | | | |
| | | | 5 | PLUG (FILL -) | | | | | | | | | | | | | |
| | | | 522 | ROD | ZBR56130 | ZBR56140 | ZBR56150 | ZBR56160 | ZBR56170 | ZBR56180 | | | | | | | |
| | 523 | TIE ROD KIT (PUMP BODY -) | 66 | SCREW | | | | | | | | | | | | | |
| | | | 92 | WASHER | | | | | | | | | | | | | |